



## 34 1171

34 1171 09039 (b=32,5 h=70)  
 34 1171 170 (abschließbar)  
 34 1171 076 (Druckknopf)

## 34 1173

34 1173 09039 (b=32,5 h=70)  
 34 1173 170 (abschließbar)  
 34 1173 076 (Druckknopf)

3d



[fsb.de/341171](https://fsb.de/341171)

[fsb.de/341173](https://fsb.de/341173)