


## 34 1226 ■

34 1226 09039 (b=32,5 h=70)  
 34 1226 170 (abschließbar)  
 34 1226 076 (Druckknopf)

Design: Werner Aisslinger




## 34 1229 ■

34 1229 49039 (b=32,5 h=70 rechts)  
 34 1229 59039 (b=32,5 h=70 links)  
 34 1229 470 (abschließbar rechts)  
 34 1229 570 (abschließbar links)

Design: Matthias Sauerbruch und Louisa Hutton



Abbildung: rechts



[fsb.de/341226](https://fsb.de/341226)

[fsb.de/341229](https://fsb.de/341229)