


In the 1920s, Robert Mallet-Stevens mitred two sections of tubing together to create the FSB 1076. Ludwig Wittgenstein bent brass tubing for the FSB 1147. And Walter Gropius and Adolf Meyer married an angled spindle to a handle bushing to produce the FSB 1102. But to this day we still don't know who it was that picked up a saw and 'liberated' the FSB 1147 from its hemispherical tip.




EN 179 model: FSB 1070
Lever handle with return-to-door

Other variants:
– square roses
– oval/angular backplates

Plug-in handle for doors

15 1075




4

Window handle

Plug-in handle for windows


34 1075




Custom-coordinated lifting/sliding door handle available upon request, see page 10

Lever/lever sets


Broad backplate sets available upon request; for flush-fitted roses, see page 386 f.




➤ 12 1075 013 (N)




➤ 15 1075 013 (N)



➤ 12 1075 007 (N)



➤ 12 1075 027 (N)




➤ 13 4223 041 (R) with
10 1075 00500 (N)
➤ 13 4223 042 (R) with
12 1075 013 (N)


➤ 13 4223 051 (L) with
10 1075 00500 (N)
➤ 13 4223 052 (L) with
12 1075 013 (N)

Lever/knob sets


Broad backplate sets available upon request; for associated knobs, see page 328 f.



➤ 12 1075 015 (N)




➤ 12 1075 009 (N)





➤ 12 1075 029 (N)


WC sets


Broad backplate sets available upon request; for flush-fitted roses, see page 386 f.





 12 1075 019 (N)




 15 1075 019 (N)



 12 1075 011 (N)



 12 1075 031 (N)

Window handles




Custom-coordinated lifting/sliding door handle available upon request, see page 10



- 34 1075 09030 (rose 27 × 62 × 10)
- 34 1075 09039 (rose 32.5 × 70 × 10)
- 34 1075 09034 (rose 25.5 × 60.5 flush-fitted)
- 34 1075 170 (lock adaptor RC 1–6)
- 34 1075 076 (lock adaptor with push-button RC 1–6)
- 34 1075 711 (plug-in handle for timber/metal profiles, Ø 30)
- 34 1075 751 (plug-in handle for PVC profiles, Ø 30)

N = non-handed
 R = DIN RH, opening inwards
 L = DIN LH, opening inwards
 ILS = inactive-leaf set

 Female handles
 Plug-in handle for doors
 FSB ASL®

 FSB AGL®
 FS heavy-duty fitting
 EN 179 heavy-duty fitting

For bearings, see page 52 ff.