


Architect Peter Bastian wanted his handle to make a dignified impact on tall, large-format doors despite being pared down to an almost doctrinaire degree. The result is a very neatly designed lever handle that offers the hand plenty of squareness to get hold of.




Design: Peter Bastian

🔑 EN 179 model: FSB 1002
 Lever handle with return-to-door

Other variants:
 – square roses
 – oval/angular backplates

Plug-in handle for doors

15 1001




4

Window handle

Plug-in handle for windows


34 1001



Lever handles for narrow-stile doors


09 1002 (in-line, EN 179)
06 1002 (cranked, EN 179)

Option without return-to-door:
09 1001 (in-line)
06 1001 (cranked)




Doorknob for narrow-stile doors

07 0809 (cranked)



Glass door fitting

13 4220 with 10 1001




4

Lever/knob sets

Doorknob for flush doors

Knob backplates


Aluminium $\varnothing = 50$



Product codes for the lever/knob sets can be found on the following pages; for individual components, see page 328 ff.


Lever/lever sets

Broad backplate sets available upon request; for flush-fitted roses, see page 536 f.




- 12 1001 013 (N)
- 72 1001 613 (R)
- 76 1001 613 (R)
- 79 1002 613 (R)

- 72 1001 614 (L)
- 76 1001 614 (L)
- 79 1002 614 (L)




- 15 1001 013 (N)




- 12 1001 001 (N)
- 72 1001 601 (R)
- 76 1001 601 (R)
- 79 1002 601 (R)

- 72 1001 602 (L)
- 76 1001 602 (L)
- 79 1002 602 (L)



- 12 1001 021 (N)
- 72 1001 621 (R)
- 76 1001 621 (R)
- 79 1002 621 (R)


- 72 1001 622 (L)
- 76 1001 622 (L)
- 79 1002 622 (L)




- 13 4220 041 (R) with 10 1001 00500 (N)
- 13 4220 042 (R) with 12 1001 013 (N)
- 13 4220 042 (R) with 72 1001 613 (R)

- 13 4220 051 (L) with 10 1001 00500 (N)
- 13 4220 052 (L) with 12 1001 013 (N)
- 13 4220 052 (L) with 72 1001 614 (L)

Sets for narrow-stile doors



- 09 1001 211
- 09 1001 212
- 09 1002 212
- 09 1002 223 (ILS)



- 06 1001 111
- 06 1001 112
- 06 1002 112

- 06 1001 023 (ILS)
- 06 1002 023 (ILS)




- 07 0809 228 (fixed)
- 07 0809 428 (fixed)




- 17 1757

Lever/knob sets


Broad backplate sets available upon request; for flush-fitted roses, see page 536 f.



- 12 1001 017 (N)
- 72 1001 617 (R)
- 76 1001 617 (R)
- 79 1002 617 (R)
- 79 1002 619 (ILS)
- 72 1001 618 (L)
- 76 1001 618 (L)
- 79 1002 618 (L)




- 12 1001 003 (N)
- 72 1001 603 (R)
- 76 1001 603 (R)
- 79 1002 603 (R)
- 79 1002 605 (ILS)
- 72 1001 604 (L)
- 76 1001 604 (L)
- 79 1002 604 (L)




- 12 1001 023 (N)
- 72 1001 623 (R)
- 76 1001 623 (R)
- 79 1002 623 (R)
- 79 1002 625 (ILS)
- 72 1001 624 (L)
- 76 1001 624 (L)
- 79 1002 624 (L)

WC sets


Broad backplate sets available upon request; for flush-fitted roses, see page 536 f.




- 12 1001 019 (N)
- 72 1001 619 (R)
- 72 1001 620 (L)



- 15 1001 019 (N)



- 12 1001 005 (N)
- 72 1001 605 (R)
- 72 1001 606 (L)



- 12 1001 025 (N)
- 72 1001 625 (R)
- 72 1001 626 (L)

Window handles



- 34 1001 09030 (rose 27 × 62 × 10)
- 34 1001 09039 (rose 32.5 × 70 × 10)
- 34 1001 09034 (rose 25.5 × 60.5 flush-fitted)
- 34 1001 170 (lock adaptor RC 1–6)
- 34 1001 076 (lock adaptor with push-button RC 1–6)
- 34 1001 711 (plug-in handle for timber/metal profiles, Ø 30)
- 34 1001 751 (plug-in handle for PVC profiles, Ø 30)
- 34 1001 714 (plug-in handle, lock adaptor RC 1–6)
- 34 1001 717 (plug-in handle with push-button RC 1–6)

N = non-handed
 R = DIN RH, opening inwards
 L = DIN LH, opening inwards
 ILS = inactive-leaf set

Female handles
 Plug-in handle for doors
 FSB ASL®

FSB AGL®
 FS heavy-duty fitting
 EN 179 heavy-duty fitting

For bearings, see page 52 ff.